




# TOP AND CONSOLE PARTS

For Models: LER4634EQ2, LER4634EZ2  
(Designer White) (Designer Almond)

ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Models: LER4634EQ2, LER4634EZ2  
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console	11		Cover, Lint Screen	31	3394290	Harness, Wiring
3	3390646	Screw, 8-18 x 5/16		688150	White	39	3395382	Switch, Push-To-Start
4		Cap, End (L.H.)	12	339229	Hinge, R.H.	48		Timer Knob Assembly
	3358528	White		339230	Hinge, L.H.		3406143	White
	3358529	Almond	13	688983	Screw, 8-18 x 5/8		3406144	Almond
5	3936144	Connector	15	693995	Screw, Hex Head	53	8054298	Bracket, Control
6	388326	Screw, Console	16		Top	54		Panel, Control
7	3395683	Housing, Connector (Motor)		3396022	White		3976748	White
8		Cap, End (R.H.)		3396023	Almond		3976749	Almond
	3358513	White	17	3394427	Clip, Harness	81		Knob, Push To Start
	3358514	Almond	19	94614	Terminal		3406133	White
9	3400859	Screw, Grounding	20	3401076	Resistor Assembly		3406134	Almond
10	339392	Screen, Lint	21	3976569	Timer, 60 Hz.			
			30	357213	Nut, Push-In (2)			


## LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>LITERATURE PARTS</b>			<b>OPTIONAL PARTS NOT INCLUDED</b>					
	LIT3406071	Use & Care Guide	<b>PAINT, TOUCH-UP (1/2oz.)</b>			<b>PAINT, BULK (1 qt.)</b>		
	LIT3397618	Instructions, Installation		72017	White		799344	White (Uncut)
	LIT3406688	Label, Wiring Diagram		72107	Almond		978883	Almond (Uncut)
			<b>PAINT, PRESSURIZED SPRAY (13 oz.)</b>			<b>Following May Be Purchased</b>		
				350930	White	<b>DO-IT-YOURSELF REPAIR MANUALS</b>		
				350956	Almond	LIT677818 Dryer		
				350938	Primer, Gray			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: LER4634EQ2, LER4634EZ2  
(Designer White) (Designer Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: LER4634EQ2, LER4634EZ2  
(Designer White) (Designer Almond)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	3393008	Screw, 10–16 x 1/2	18		Cabinet	38	349464	Seal & Bearing
3		Plug, Strike			(Includes Illus.			Assembly
		Hole			Nos. 5, 7, 16,	40	279393	Terminal Block
	3403630	White			29, 41 & 57)			Kit For
	3403631	Almond		3399580	White			Terminal Block
4	238614	Bumper		3399581	Almond	41	3397659	Block, Terminal
5	3396795	Cover, Terminal	19	98234	Clip, Ground	51	238088	Hinge, Top (2)
		Block	20	690363	Lock, Front	53	691366	Idler & Pulley
7	3396807	Panel, Rear			Top (2)			Assembly
8		Plug, Hinge	21		Front Panel	56	660996	Belt, Drive
		Hole (4)			Assembly	57	348780	Base, Motor
	3404413	White		3403571	White	58	3400500	Bolt,
	3404414	Almond		3403572	Almond			5/16–18 x 3/4
9	342055	Screw, 8–18 x 1/2	23	685203	Clip, Felt Pad	59	3401143	Pulley, 60 Hz.
10	3406104	Door Switch	24	690081	Catch, Door	62	3395652	Motor Assembly
		Assembly	28	3405514	Hinge & Pin			60 Hz.
11	697773	Screw,			Assembly	63	660658	Clamp, Motor
		6–20 x 7/8 (2)	29	3394083	Clip, Front	64	3404162	Clamp, Motor
13	693995	Screw, Rear Panel			Panel (2)			(W/Shield)
		Mounting	33	3403431	Strike, Door	67	3405245	Seal, Door
16	3392100	Foot, Dryer	35	3403371	Door, Rear	87	697776	Screw, 10–32 x 1/2
	279810	Foot – Optional	36		Door Front			(External Ground)
		(Extended Length		3403361	White	90	279318	Terminal, Tinned
		Package Of 2)		3403362	Almond			& Brass (3)
		(Not Included)	37		Handle, Door			(Includes Illus. 40)
17	343641	Screw,		3405184	White			
		10–16 x 1/2		3405185	Almond			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: LER4634EQ2, LER4634EZ2  
(Designer White) (Designer Almond)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
4	3388703	Washer, Support
5	90767	Screw, 8 x 3/8
6	3399848	Thermal Cut-Off (Hi-Limit Thermostat Illus. No.15 Included)
7	347139	Seal, Lint Chute
9	3392247	Pad, Blower Housing
10	694089	Wheel, Blower
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	3397566	Box, Heater

Illus. No.	Part No.	DESCRIPTION
15	3399693	Thermostat, High Limit 250°F (121.1°C) (60 Hz.)
16	3394196	Seal, Blower Shaft
17	3403585	Element, Heater (For 240 Volt Installation)
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
23	3392519	Fuse, Thermal
24	3387134	Thermostat, Internal-Bias
41	690997	Ring, Tri

Illus. No.	Part No.	DESCRIPTION
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3397264	Bulkhead
62	3394509	Ring, Bearing
63	97787	Screw, 11-16 x 7/8
66	337449	Seal, Rear Drum
67	3396777	Drum Assembly
68	342847	Baffle, Drum
69	3976435	Bracket, Support
70	90296	Clip
73	339956	Seal
74	489463	Screw
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST